



**234PIE3**    3HP 3 Phase  
**234PIE5**    5HP 3 Phase  
**234PIE51**   5HP 1 Phase



234PIE3  
 234PIE5  
 234PIE51

ITEM	PART #	DESCRIPTION	QTY	QTY	QTY
1	17000	Outlet Flange	1	1	1
	M17000	Outlet Flange, Manifold (Opt)	1	1	1
2	17002	Inlet Flange	1	1	1
	M17002	Inlet Flange, Manifold (Opt)	1	1	1
3	17046	C-Flange Adpt. 56C/143TC/145TC	1		
	17446	C-Flange Adpt. 182TC, 184TC		1	1
4	17005	Impeller Shaft 5/8" ID			
	17007	Impeller Shaft 7/8" ID	1		
	17406	Impeller Shaft 1-1/8" ID		1	1
5	17008	Impeller - 5" Dia	1		
	17408	Impeller		1	1
6	17009B	5/8" Impeller Nut	1	1	1
7	17010	1/2" Hex Nut	1	1	1
8	17011	Wear Plate	1	1	1
9	17013	Outlet Gasket	1	1	1
10	17016	Gasket & Check Valve	1	1	1
11	17018	Gasket Adapter	1	1	1
12	17019	Bolt	8	8	8
13	15022	Handle	1	1	1
14	17024	Clamp Assembly w/Key 7/8"	1		
	18128	Clamp Assembly w/Key 1-1/8"		1	1
15	17026	Pump Housing	1	1	1
16	V10118	5/16" Lock Washer	20	20	20
17	17042	Housing Stud	6	6	6
18	V10119	Hex Nut	8	8	8
19	17449	Bolt	4	4	4
20	18058	Washer	4	4	4
21	17035	Seal Assembly	1	1	1
	17035SD	Seal, Severe Duty	1		
	18025	Seal Assembly		1	1
	18025SD	Seal, Severe Duty		1	1
22	17701	Base Plate Assembly	1	1	1
23	17704	Bolt	4	4	4
24	V20018	3/8" Lock Washer	4	4	4
25	17130	Flat Head Screw	2	2	2
26	BEM3	Electric Motor - 3 Phase 3HP	1		
	BEM5	Electric Motor - 3 Phase 5HP		1	
	BEM51	Electric Motor - 1 Phase 5HP			1
27	12777	Drain Plug	1	1	1
28	UV15163	O-Ring for Drain Plug	1	1	1

**Spray**   
**Advantage**



Place spacer between wear plate and impeller and do not remove until bolted to drive shaft

Impeller/Wear Plate Clearance  
 .025" - .035"